

RUST-OLEUM®
INDUSTRIAL



HARD HAT® TOPCOAT RAL-COLOURS

The Nr. 1 Industrial Paint Aerosol!

- Top quality
- For on bare metal, wood and concrete
- To handle after 30 minutes (at 20°C)
- Best available hiding power
- Heat-resistant up to 100 °C

KNOW-HOW TO PROTECT™

WWW.RUST-OLEUM.EU

HARD HAT® TOPCOAT RAL-COLOURS

BESKRIVNING

Hard Hat® Aerosol Topcoats 2100 are based on a fast drying short oil soya alkyd. The products are based on lead- and chromate free pigments.

REKOMMENDERAD ANVÄNDNING

RUST-OLEUM Topcoats 2100 should be applied over RUST-OLEUM Hard Hat 2169/2182 Primers or properly prepared painted substrates. RUST-OLEUM Topcoats 2100 are intended for small maintenance jobs or for touch-up. RUST-OLEUM Topcoats 2100 should be used in light industrial exposures, normal humidity and interior applications.

TEKNISK DATA

Glansnivå: Glans, Matt, Satin
Värmebeständighet: 100°C (dry heat), above 65°C discoloration may occur

TORKTIDER VID 20°C/RELATIV LUFTFUKTIGHET 50%

Beröringstorr: 15 minutes
Hanteringstorr: 30 minutes
Torktid: Within 1 hour or after 48 hours
Fullt härdad: 7 days

REKOMMENDERAD VÅTFILMSTJOCKLEK

100 µm

REKOMMENDERAD TORRFILMSTJOCKLEK

25 µm

ÅTGÅNG

2.5 m² per spray can at 25 µm dry

ÅTGÅNG INFORMATION

Practical coverage depends on many factors such as porosity and roughness of the substrate and material losses during application.

FÖRBEREDELSE

Remove dirt, grease, oil, loose rust and all other surface contaminants by appropriate means. Prime or spot prime with the recommended RUST-OLEUM Primers. Sand intact coatings to provide a proper key for adhesion. The surface must be clean and dry during application.

APPLICERINGSFÖRHÅLLANDEN

For good results the relative humidity shall be below 85% and the temperature of the can above and substrate 0°C.

APPLICERING OCH SPÄDNING: AEROSOL

Remove cover cap. Shake vigorously for at least one minute after the rattle of mixing ball is heard. Shake frequently during use. Hold can approx. 25 cm from surface. Use back and forth motion keeping can parallel with surface. Ensure that can is in motion when spray button is pressed to avoid runs and sags. Apply several thin layers at a few minutes interval to achieve adequate coating thickness. After use turn can upside down and press spray button for 2 - 3 seconds to clean valve.

Utgivningsdatum: 20/03/2025

Tillgängliga färger och förpackningsstorlekar: Se respektive produktsida på www.rust-oleum.eu för en översikt över tillgängliga färger och förpackningsstorlekar.

Förbehåll: Informationen i detta produktdatablad är korrekt så långt vi känner till och ges i god tro men utan garanti. Vi förutsätter att användaren självständigt har tagit ställning till lämpligheten av våra produkter för hans eller hennes egna syften. Under inga omständigheter är Rust-Oleum Europe ansvarigt för indirekta skador eller följdsador. Produkterna ska förvaras, hanteras och användas under förhållanden som överensstämmer med Rust-Oleum Europes rekommendationer i den senaste utgåvan av produktdatabladet. Det är användarens ansvar att säkerställa att han/hon har den aktuella utgåvan. Senaste utgåvan av produktdatabladet kan erhållas kostnadsfritt från www.rust-oleum.eu eller vår kundtjänst. Rust-Oleum Europe förbehåller sig rätten att ändra egenskaperna i sina produkter utan föregående avisering.

Rust-Oleum Netherlands B.V.
Zilverenberg 16
5234 GM 's-Hertogenbosch
The Netherlands
T: +31 (0) 165 593 636
F: +31 (0) 165 593 600
info@rust-oleum.eu

Tor Coatings Ltd (Rust-Oleum Industrial)
Shadon Way, Portobello Ind. Estate
Birtley, Chester-le-Street
DH3 2RE United Kingdom
T: +44 (0)1914 113 146
F: +44 (0)1914 113 147
info@rust-oleum.eu

Rust-Oleum France S.A.S.
38, av. du Gros Chêne
95322 Herblay
France
T: +33(0) 130 40 00 44
F: +33(0) 130 40 99 80
info@rust-oleum.eu

N.V. Martin Mathys S.A.
Kolenbergstraat 23
3545 Zelem
Belgium
T: +32 (0) 13 460 200
F: +32 (0) 13 460 201
info@rust-oleum.eu